





## NOTES:

- FASTENING PATTERNS ARE PROVIDED AS GUIDELINES FOR FASTENER PLACEMENT FOR MECHANICALLY ATTACHED INSULATION OR COVER BOARD UNDER A FULLY ADHERED MEMBRANE SYSTEM.
- AN APPROVED COVER BOARD IS REQUIRED FOR EPS, XPS, & POLYISOCYANURATE INSULATIONS NOT APPROVED BY IB ROOF SYSTEMS.
- 3. REFER TO TABLE A.2 FFOR MINIMUM REQUIREMENTS FOR INSULATION FASTENER SCHEDULE FOR ADHERED IB ROOF MEMBRANES.

Scale:	Detail Name:  1 Per 2.3 Fastening Patterns for Insulation/Cover Board		Detail Number: FA-AT-06
Submitted By: Address:		Project: Address:	
Telephone:		Addison	