



NOTES:

1. IB EDGE METAL TO BE FASTENED WITH RING SHANK NAILS AT 4" O.C. STAGGERED, OR WITH IB FASTENERS AT 12" O.C.
2. SECURE FLASHINGS AND METAL WORK IN ACCORDANCE WITH IB SPECIFICATIONS AND FLASHING SECUREMENT TABLE.
3. PROVIDE 1/4" SPACE AT METAL JOINTS. SECURE EACH SIDE WITH TWO FASTENERS. COVER JOINT ALONG DECK FLANGE AND FASCIA WITH 2" WIDE IB FOIL TAPE. INSTALL 5" X 8" NON-REINFORCED IB FLASHING CENTERED OVER THE JOINT AND INSTALL FIELD MEMBRANE.

Scale: NTS	Detail Name: <div style="text-align: center; font-size: 1.2em; font-weight: bold;">IB Clad Drip Edge</div>	Detail Number: <div style="text-align: center; font-size: 1.2em; font-weight: bold;">DS-PE-01</div>
Submitted By: Address: Telephone:		Project: Address: