





NOTES:

- 1. FASTENING PATTERNS ARE PROVIDED AS GUIDELINES FOR FASTENER PLACEMENT FOR MECHANICALLY ATTACHED INSULATION OR COVER BOARD UNDER A FULLY ADHERED MEMBRANE SYSTEM.
- 2. AN APPROVED COVER BOARD IS REQUIRED FOR EPS, XPS, & POLYISOCYANURATE INSULATIONS NOT APPROVED BY IB ROOF SYSTEMS.

Scale: NTS	1 Per 3.2 Fastening Patterns for Insulation/Cover Board		FA-AT-03
Submitte Addre Telepho	ess:	Project: Address:	